


Belt-Way Scales

Conveyer Belt Scales

Belt-Way[®]

Touchscreen Remote Display



SCALE / PRODUCT	TOTAL TONS	TONS / HR	FEET / MIN	LOAD %	SET ZERO	RESET TONS
PRIMARY	941	621	446	61	START	
SHOTROCK	294	207	461	37	START	
CV2	188	124	281	56	START	
STONES	78	81	288	48	START	
CV5	197	214	387	51	START	
3/4 ROAD	31	18	415	42	START	
CV8	37	39	259	39	START	
SAND	114	137	338	46	START	
CV13						
GRAVEL						
CV12						
FINES						
FEED						
DUST						
DISCHARGE						
LIME						
MENU HELP Date: 10/15/2010 Time: 09:10						

Functions

- Monitor Multiple Scales on 1 Display
- Clear Totals for Any or All Scales
- Re-Zero Any or All Belts
- Fingertip Access to All MENUS
- Wireless Connection

Features

- Total Tons Graph
- TPH Graph
- Daily, Weekly, Monthly Totals
- Down-Time per Shift
- Percentage of Target Production per Shift
- Download Data Log to USB Key
- Print Production Reports

